

Quick Start Guide

Switching On / Off

Press the on switch.

Start-up routine and self check can take a few minutes – turning it off can take a few seconds. All LEDs will blink (all colors).





Comfort Level

Press the  - Button repeatedly to change the Comfort Level.

More blue LEDs mean a more active operation (minimum ventilation, humidity, CO2, cooling ... etc.). However, a change in Comfort Level does not have to lead to the immediate increase in fan speed.

Blinking or flashing blue LEDs indicate Service or Dehumidification Operation.

Turbo / Sleep / Turbo Cool

Push the  - Button until you hear 4 short beeps. This should be selected if you wish to air out rooms at the highest device setting for 30 minutes. Push and hold the  - Button longer and your freeAir100 will pause for 90 minutes.

To start Turbo Cool Function for a maximum duration of 3 hours push and hold the button yet longer for.

